



# RAM

Fitment guide for the 6.4Ft canopies.

## CONTENTS


<b>1. Getting Started:</b>	2
<b>1.1 Fitment kit contents:</b>	2
<b>2. Fitment guide:</b>	3
<b>2.1 Installation time &amp; care instructions:</b>	3
<b>2.2 Tools required for fitment:</b>	3
<b>2.3 Step 1 – Prepare the vehicle for fitment:</b>	3
<b>2.4 Step 2 – Place the canopy onto the vehicle load bed:</b>	3
<b>2.5 Step 3 – Secure the canopy to the load bed:</b>	5
<b>2. Notes:</b>	5

## 1. Getting Started:

### 1.1 Fitment kit contents:



Please ensure that all the contents are received as listed below.



A. Dodge RAM 2500 Aluminium canopy	x 1
B. M8 x 45 Hexagonal Screw	x 8
C. M8 Body Washer	x 16
D. M8 Nyloc nut	x 8

FOR ANY FURTHER INFORMATION, PLEASE CONTACT YOUR INTERNATIONAL DEALER

## 2. Fitment guide:

### 2.1 Installation time & care instructions:

The fitment duration is approximately 45 minutes.

**PLEASE  
NOTE...**

The fitment of the canopy will require a minimum of 4 x people to lift the canopy onto the vehicle.

Torque all M8 fasteners to approx. 28Nm.



Before installation, ensure that your hands and workwear are clean from oil, grime & dirt.

Ensure that the correct tools and PPE are used whilst installing the canopy. Clean the rear cab window before fitting the canopy.

### 2.2 Tools required for fitment:

IMPACT DRILL



- 1 x Ø9 Drill bit

COMBINATION WRENCH



- 1 x 13mm Spanner

SOCKET WRENCH



- 1 x 13mm Socket

TORQUE WRENCH



- 1 x 13mm Socket




### 2.3 Step 1 – Prepare the vehicle for fitment:

- Remove any cab guards, roll bar, tonneau cover, sports bar and any accessory that might cause an obstruction for the fitment of the canopy.

### 2.4 Step 2 – Place the canopy onto the vehicle load bed:

- Place the canopy onto the vehicle load bed.
- The bottom edge of the canopy front panel should be approximately 5mm / 3/16" from the load bed's front panel edge. Fig. 2.4.1.
- Observe the sides of the canopy compared to the load bed to confirm that the canopy is positioned center to the load bed.
- Once the canopy is in position, identify the 8 x dedicated fitment holes on both sides on the inside of the canopy as illustrated in Fig. 2.4.2. and mark the hole positions on the canopy load bed.
- Remove the canopy and drill Ø9mm holes through the top of the load bed surface.

FOR ANY FURTHER INFORMATION, PLEASE CONTACT YOUR INTERNATIONAL DEALER



FOR ANY FURTHER INFORMATION, PLEASE CONTACT YOUR INTERNATIONAL DEALER

### 2.5 Step 3 – Secure the canopy to the load bed:

- Place the canopy back onto the vehicle load bed, with the dedicated fitment holes in the canopy align with the previously drilled holes on the load bed.
- Secure the canopy to each hole in the load bed by means of a M8 body washer and M8 x 45 Hexagonal screw from the top, then a M8 body washer and M8 Nyloc nut from the bottom. Lightly fasten all fasteners. Fig. 2.5
- Confirm the canopy position compared to the load bed one final time, secure all fasteners to approx. 28 Nm.




Fig. 2.5

### 2. Notes:

- You have now successfully completed the fitment of your Aluminium canopy.
- Confirm that all the fitment screws have been properly torqued one last time.
- Be sure to check at least bi-monthly that all the screws are still properly tightened.

FOR ANY FURTHER INFORMATION, PLEASE CONTACT YOUR INTERNATIONAL DEALER